



Serving Tray




Print all three pages and line them up, then tape them together where they overlap.
Use a ruler to make sure the dimensions of your printout are correct.
Make sure you select the "Actual Size" option in your print settings prior to printing.
(Other options, such as "Fit to Page" will throw off the dimensions.)

Serving Tray



Print all three pages and line them up, then tape them together where they overlap.
Use a ruler to make sure the dimensions of your printout are correct.
Make sure you select the "Actual Size" option in your print settings prior to printing.
(Other options, such as "Fit to Page" will throw off the dimensions.)

Serving Tray



Print all three pages and line them up, then tape them together where they overlap.
Use a ruler to make sure the dimensions of your printout are correct.
Make sure you select the "Actual Size" option in your print settings prior to printing.
(Other options, such as "Fit to Page" will throw off the dimensions.)